

Bollard Signs

01



Take out your bollard sign and place it on a flat surface. The print should be facing upwards.

02



Carefully fold each crease on the printed side first following the crease lines. Use the side of your palm to help you crease in the correct spot.

03



Pre-creasing it will help hold its shape once it has been assembled.

04



Flip your bollard sign over. The print should now be facing downwards.

05



Fold each crease again on the back side following the crease lines. Use the side of your palm to help you crease in the correct spot.

06



Fold your bollard sign in the correct shape.

Bollard Signs

07



Insert the outer tabs first using the self-locking system to hold the shape in place.

08



The bigger tab slots inside the bigger hole, and the smaller tab slots inside the smaller hole.

09



Insert the inner tabs using the self-locking system in the same manner as Step 7&8.

10



You should now have an awesome looking bollard sign!