Assembly Guide 1/2

Director Chairs

01

Contents include: 1 wooden chair frame, 1 backrest, 1 seat, and 2 wooden seat dowels.

02

Insert one of the wooden seat dowels into the sleeve on the seat.

03

Repeat this step on the opposite side.

04

Stand the chair upright on its legs and open it approximately three-quarters of the way. (Do not fully open the chair at this stage, as this may make attaching the seat and backrest difficult.)

05

Slide the seat, with the inserted dowel, into the seat channel.

06

Repeat this step on the opposite side, then slide the seat along the seat channels until centred.

Assembly Guide 2/2

Director Chairs

07

Lift the first armrest into a vertical position.

08

Slide the backrest sleeve onto the armrest pole.

09

Repeat this step on the opposite side.

10

At this stage, fully open the chair by pushing down on the armrests. This will tension the seat and backrest into position.

11

Push down firmly on both the front and rear hinges until they lock securely into place.

12

Easy as that! Assembly complete.