



Custom Mailer Box Assembly Guide

All Box Sizes



Step 1: Fold all edges along the crease lines which indicates where your box will be further folded. *Note: Do not press the fold lines with too much strength. The fold angle should not be bigger than 90-degrees.*



Step 2: Carefully fold in the interior walls of your box.



Step 3: Tuck your sides into the interior of the box. The locking tabs should fit nicely into the slot at the bottom of your packaging.



Step 4: Fold the remaining sides of your box. The wings should fit nicely into the side panels.



Step 5: Your mailer box is ready to go!