Care Guide

Replacement Flags

Feather Flags, Teardrop Flags, Rectangle Flags, Real Estate Flags

Maintenance

Make sure that you assemble the Flag correctly in accordance with our assembly guide.
Your flag will arrive folded into a neat package and may arrive with some creases. These creases should come out naturally over time when used outdoors. However if you would like to quickly remove the creaes the most effective method is with a steamer.

Cleaning

We recommend that the flag is cleaned regularly. To clean the fabric use a mild detergent in warm water with a soft mop or cloth. It is important to note that no solvents or abrasive cleaners should be used on any part of the fabric. To avoid the growth of mildew it is important that the fabric is completely dry before being packed away.

General Use

The flags should not be used in extreme weather conditions to avoid possible damage.

When assembling the flags be mindful of it's surroundings to minimise any damage, make sure it's clear of sharp objects to avoid wear and tear.



